








# CLEANROOM IP65 LED

## INSTALLATION INSTRUCTIONS

eaglelightingaustralia  
Member of the Fagerhult Group

### SPECIFICATION

	Luminaire's light distribution is direct.
<b>LED</b>	Denotes which light source/light sources that can be supplied with the luminaire. Several symbols next to the same luminaire indicate that the luminaire is available in different designs.
<b>IP65</b>	<b>IP CLASSIFICATION</b> IP65 : No ingress of dust; complete protection against contact (dust tight). Protected against low pressure jets of water from all directions.
	<b>CLASS I</b> Appliances with functioning insulation. Equipped with an earth termination.
	<b>RISK OF FIRE</b> Building Insulation must not cover this Luminaire HCB =100mm. MIC =100mm. SCB =100mm. SCI =100mm.
	Luminaire is available in designs for conventional emergency lighting operation.
	<b>RCM</b> Indicates a device's compliance with applicable ACMA technical standards.
	<b>ESD</b> Personnel should be grounded when unpacking or handling the luminaire.
	<b>High Voltage</b> Luminaire circuitry exceeds a forward voltage of 50V.

### IMPORTANT INFORMATION

Please read this guide carefully before installing or maintaining this equipment.

Data should be used as an **INDICATION** only.

Good electrical practices should be followed at all times.

Must only be installed by a licensed electrician.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or their service agent or a similar qualified person in order to avoid a hazard.

For indoor use only.

A qualified electrician, in accordance with AS/NZS 3000:2007 wiring regulations should carry out connection to mains wiring.

This unit must be **EARTHED**.

Ensure that the rated voltage and frequency requirements are compatible with the available mains supply, 220-240V 50Hz.

Cleaning of reflectors and lenses should be carried out using clean, soft and lint free cloths and anti-static cleaning fluid.

Do not carry out high voltage insulation test i.e. 500/1000V this may damage the fixtures electrical components.

CODE INS-CR65L

MELBOURNE | 17-19 Jets Court, Melbourne Airport, VIC 3045 P.03 9344 7444 F.03 9344 7433

SYDNEY | Unit 4, 21 Mars Road, Lane Cove, NSW 2066 P.02 9420 5799 F.02 9420 5988

BRISBANE | 53 Caswell Street, East Brisbane, QLD 4169 P.07 3891 0744 F.07 3891 0755

# CLEANROOM IP65 LED

## INSTALLATION INSTRUCTIONS


eaglelightingaustralia  
Member of the Fagerhult Group

### EXPOSED T-BAR

- Step 1  
Lift the luminaire into the ceiling cavity.
- Step 2  
Complete the electrical connection.
- Step 3  
Position the luminaire centrally within the T-Bar.

### PLASTER CEILING

- Step 1  
Starting from one corner release frame from base with the suction cup. Frame will still remain attached to base via wire lanyards.




- Step 2  
Disconnect lanyards to release the frame from base.

- Step 3  
Lift the luminaire into the ceiling cavity, ensuring the toggle arms are turned in and run flush against body of fitting so it will enter ceiling cut out. Using Phillips head screwdriver, turn screw anti-clockwise to ensure toggle recess arms are set to maximum travel to allow a maximum ceiling thickness of 50mm.

**\*Note: Ensure the ceiling has been reinforced around the cut out. Reinforcement to be fixed to the ceiling.**


- Step 4  
Use a Phillips head screwdriver in a clockwise direction to tension up toggle recess arms against inside of ceiling. Perform this on all six screws to secure fitting to ceiling.

- Step 5  
Reattach all lanyards to frame, including earthing lanyard. Reattach frame assembly to main body starting at one end and then slowly pushing up other end until magnets pull the frame shut.



### SURFACE MOUNTED

- Step 1  
Remove the diffuser frame and gear tray from the luminaire



- Step 2  
Lift the surface mounted luminaire to the ceiling, feeding the supply cable through the cable entry hole.

- Step 3  
Secure the luminaire onto the mounting surface with appropriate fasteners (not supplied) to suit the mounting substrate.

- Step 4  
Complete electrical connection and re install the gear tray.

- Step 5  
Reattach all lanyards to frame, including earthing lanyard. Reattach frame assembly to main body starting at one end and then slowly pushing up other end until magnets pull the frame shut.



CODE INS-CR65L

MELBOURNE | 17-19 Jets Court, Melbourne Airport, VIC 3045 P.03 9344 7444 F.03 9344 7433

SYDNEY | Unit 4, 21 Mars Road, Lane Cove, NSW 2066 P.02 9420 5799 F.02 9420 5988

BRISBANE | 53 Caswell Street, East Brisbane, QLD 4169 P.07 3891 0744 F.07 3891 0755